



Cloud Computing and Virtualization Lab


Presented by:

Saurabh Singhal


Assistant Professor



- 2 PC
- 1 Switch
- 1 Printer










Assign the IP to printer






Click on PC and ping 192.168.1.3

```
Physical
         Confia
                 Desktop
                          Programming
                                       Attributes
Command Prompt
 Packet Tracer PC Command Line 1.0
C:\>ping 192.168.1.3
 Pinging 192.168.1.3 with 32 bytes of data:
Reply from 192.168.1.3: bytes=32 time=1ms TTL=128
 Reply from 192.168.1.3: bytes=32 time<1ms TTL=128
 Reply from 192.168.1.3: bytes=32 time<1ms TTL=128
 Reply from 192.168.1.3: bytes=32 time<1ms TTL=128
 Ping statistics for 192.168.1.3:
     Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
 Approximate round trip times in milli-seconds:
     Minimum = 0ms, Maximum = 1ms, Average = 0ms
 C:\>
```





- Click on simulation
- Click on show all/none
- Click on edit filters
- Select ICMP





- Select PDU and first click on any PC and then on Printer.
- Trace the activity of packet using Auto







FTP

- The File Transfer Protocol is a standard network protocol used for the transfer of computer files between a client and server on a computer network.
- FTP is built on a client-server model architecture using separate control and data connections between the client and the server




FTP Server

- An FTP Server is a piece of software that is running on a computer and uses the File Transfer Protocol to store and share files.
- Remote computers can connect anonymously, if allowed, or with a user name and password in order to download files from this server using a piece of software called a FTP Client




FTP Server






FTP Server






- Click on the Server
- Click on the Desktop tab.
 - Click on the IP Configuration icon.
 - Click on the IP Address dialog box and assign following IP






- Click on the Service
 Tab
- Select FTP service
- Check whether the FTP Services are enabled
- To add user in username and password.
- Give permission
- Click on Add.






- Click on any PC
- Click on Desktop Tab and then Command Prompt.
- Type ftp and press enter
- Type username and password.
- Type dir
- Try to delete a file
- We are done with FTP server






- Click on the Server (FTP Server)
- Click on the Service Tab
- Select Email service
- Check whether the SMTP and POP3 Services are enabled
- To add a domain name
- To add at least two user
- Click on Add.






- Click on PCO, select desktop tab and chose email
- Configure mail and click on save






- Click on PC1, select desktop tab and chose email
- Configure mail and click on save






- Click on PC1, select desktop tab and chose email
- Click on compose
- Fill the entry and click on send





- Click on PC1, select desktop tab and chose email
- Click on receive. You will find your mail here

Repeat compose mail for PCO





DHCP

- Dynamic Host Configuration Protocol (DHCP) is a client/server protocol that automatically provides an Internet Protocol (IP) host with its IP address and other related configuration information such as the subnet mask and default gateway.
- A DHCP server enables computers to request IP addresses and networking parameters automatically from the Internet service provider (ISP), reducing the need for a network administrator or a user to manually assign IP addresses to all network devices



DHCP Server

- A DHCP Server is a network server that automatically provides and assigns IP addresses, default gateways and other network parameters to client devices.
- It relies on the standard protocol known as Dynamic Host Configuration Protocol or **DHCP** to respond to broadcast queries by clients.




- Click on the Server0
 - Click on the Desktop tab.
 - Click on the IP Configuration icon.
 - Click on the IP Address dialog box.
 - Type in 192.168.1.1 as the address and press enter.
 - A default value of 255.255.255.0 should appear in the Subnet Mask field.
 - Type 192.168.1.1 as the default gateway and press enter.
 - Type 0.0.0.0 as the default DNS server and press enter.



- Configure the server0
- Select the Services tab.
- Select DHCP from the SERVICES list in the left pane.
- In the DHCP configuration window, configure a DHCP as shown in the figure with the following settings.
- Click On to turn the DCHP service on
- Pool name: serverpool
- Default Gateway: 192.168.1.1
- DNS Server: 0.0 .0.0
- Starting IP Address: 192.168.1.21
- Subnet Mask 255.255.255.0
- Click save to add the pool








Create a DHCP Server

- Click on the PC connected to fa0/0
- Click on the PC icon on the Logical workspace
- Select the Desktop tab and then the IP Configuration icon
- Switch to DHCP instead of Static
- Check whether DHCP is Successful.





DNS

- The Domain Name System (DNS) is a hierarchical and decentralized naming system for computers, services, or other resources connected to the Internet or a private network.
- It associates various information with domain names assigned to each of the participating entities.
- The Domain Name System delegates the responsibility of assigning domain names and mapping those names to Internet resources by designating authoritative name servers for each domain



DNS Server

- A **DNS server** is a computer **server** that contains a database of public IP addresses and their associated hostnames, and in most cases serves to resolve, or translate, those names to IP addresses as requested.
- **DNS servers** run special software and communicate with each other using special protocols




Create a DNS Server

- Click on the Server1
 - Click on the Desktop tab.
 - Click on the IP Configuration icon.
 - Click on the IP Address dialog box.
 - Type in 192.168.1.8 as the address and press enter.
 - A default value of 255.255.255.0 should appear in the Subnet Mask field.
 - Type 192.168.1.1 as the default gateway and press enter.
 - Type 192.168.1.8 as the DNS and press enter.



Create a DHCP Server


• Update DHCP server adding DNS server(192.168.1.8) IP in IP configuration in Desktop tab





Create a DNS Server

• Update DHCP server by adding DNS server(192.168.1.8) IP in DHCP services in service tab and then save





HTTP

- HTTP means HyperText Transfer Protocol. HTTP is the underlying protocol used by the World Wide Web and this protocol defines how messages are formatted and transmitted, and what actions Web servers and browsers should take in response to various commands
- Communication between client computers and web servers is done by sending HTTP Requests and receiving HTTP Responses



HTTP Server


- A HTTP server is a computer that runs websites.
- It's a computer program that distributes web pages as they are requisitioned.



- Click on the Server3 linked to fa0/1
 - Click on the Desktop tab.
 - Click on the IP Configuration icon.
 - Click on the IP Address dialog box.
 - Type in 10.0.0.10 as the address and press enter.
 - A default value of 255.0.0.0 should appear in the Subnet Mask field.
 - Type 10.0.0.1 as the default gateway and press enter.
 - Type 192.168.1.8 as the DNS and press enter.




- Click on the Service
 Tab
- Select HTTP service
- Check whether both HTTP and HTTPS are enabled.
- To Create record on DNS Server






- Click on the Server0 (DNS Server)
- Select the service tab and Select DNS service
 - Add a name (google.com) in name and Add a 10.0.0.10 in address
 - And then click on Add






- Click on the PC
 - Click on the Desktop tab and Click on the Web Browser icon.
 - In URL type: google.com
 - We are done with HTTP/HTTPS server



Credited with A Grade by NAZ etwork Time Protocol(NTP) Server




A Grade by NAZE etwork Time Protocol(NTP) Server

- Click on the Router and type
- **no**]: no
- Router>en
- Router#conf t
- Router(config)#int fa0/0
- Router(config-if)#ip address 192.168.1.1 255.255.255.0
- Router(config-if)#no sh
- Router(config-if)#end
- Router#

Grade by NACE etwork Time Protocol(NTP) Server

Assign the IP to the server



Accredited with A Grade by NAC etwork Time Protocol(NTP) Server

Click on the router and type


Router#show clock

*0:4:50.440 UTC Mon Mar 1 1993 (please note)

Router#

Server

Click on server and NTP service




Server Server

- Router(config)#ntp?
- Router(config)#ntp server 192.168.1.2
- Router(config)#ntp authentication-key 1?
- md5 MD5 authentication
- Router(config)#ntp authentication-key 1 md5 123456
- Router(config)#ntp update-calendar
- Router(config)#end
- Router#show clock
- *0:10:37.310 UTC Mon Mar 1 1993 (compare with previous time)
- Router#




- 1 router 1841
- 1 Server





Assign the following IP to server






- Click on the Router and type
- **no**]: no
- Router>en
- Router#conf t
- Router(config)#int fa0/0
- Router(config-if)#ip address 192.168.1.1 255.255.255.0
- Router(config-if)#no sh
- Router(config-if)#end
- Router#



Check the syslog service is on at server





- Click on router and type
 - Router(config-if)#logging 192.168.1.2
 - Router(config)#logging trap debugging
 - Router(config)#logging on
 - Router(config)#int fa0/0
 - Router(config-if)#sh
 - Router(config-if)#no sh
 - Router(config-if)#exit
 - Router(config)#end
 - Router#ping 192.168.1.2
 - Router#



Check your server syslog for entries.

